



# RC-TT Range Remote Control Kit RC-TT (Rev-2)

The RC-TT Range Remote Control Kit is designed to directly interface with the popular Target Time Range Controller. It provides a wireless two button remote that can be used to replace the wired Target Time remote key pad.



The kit contains:

1. An RC-1000 two button battery powered transmitter. The unit simulates the wired Target Time start and reset buttons.
2. An RCR-1002-1 wireless receiver. This unit converts the radio signals from the hand held transmitter into control signals that replicate the Target Time wired handheld .
3. A 10' 3 pin XRL to 3 pin mini DIN cable used to connect the RCR-1002-1 receiver to the Target Time controller.
4. An AC wall plug mounted 12VDC power supply.

Operation:

1. The RCR-1002-1 receiver needs to be located in an open area close to an AC power plug and within 10' of the Target Time controller. Avoid areas that are surrounded by metal walls or in a metallic cabinet. Mount tabs on the RCR-1002-01 receiver may be used to permanently mount the receiver to a horizontal or vertical surface. An optional Velcro mounting kit and several extended length interconnect cables are available.
2. Plug the AC power supply into a 120V-240VAC power outlet. Plug the circular DC connector on the power supply cable into the +12VDC connector. It is located on the bottom edge of the RCR-1002-1 receiver. The receiver may be left on, or connected to a switched power outlet.
3. Plug the DIN end of the 3 pin mini DIN connector into the remote receptacle on the Target Time controller, and the XRL end into the control cable receptacle on the RCR-1002-1.
4. The unit is now ready to use. Depressing the START button will begin a timing cycle, and depressing the RESET button will reset that cycle.

# RC-TT Range Remote Control Kit RC-TT (Rev-2)

## UNIT PRICE LIST



Complete RC-TT Range Remote Control Unit ..... \$149.90

*Includes: RCR-1002-02 Receiver, RC-1000 Two Channel Handheld Transmitter, AC Power Supply, and 10' Cable.*



RCR-1002-02 Receiver ..... \$55.90



RC-1000 Handheld Transmitter ..... \$68.75



PS001 AC Power Supply ..... \$23.95



Interconnect Cable

10' ..... \$19.95

20' ..... \$25.95

30' ..... \$32.95



Mounting Kit ..... \$7.50

*Includes: 2" x 4.5" Velcro Mount, 2 Wire clamps and 5 Tie Wraps.*



Battery (For Handheld Transmitter) ..... \$3.10